







Operating instructions

KRAL



KRAL screw pumps.

Series K

Magnetic coupling



Observe safety instructions for persons with cardiac pacemakers, metallic implants or neurostimulators.

OIK 09en-GB
Edition 2023-12
Original instructions

www.kral.at

1 About this document	4	10.1 Dangers during operation	20
1.1 General information	4	10.2 Commissioning	21
1.2 Associated documents	4	10.2.1 Cleaning the pipe system	21
1.3 Target groups	4	10.2.2 Filling and venting the pump	21
1.4 Symbols	4	10.2.3 Checking the direction of rotation	23
1.4.1 Danger levels	4	10.2.4 Commissioning the pump	24
1.4.2 Danger signs	5	10.3 During operation	25
1.4.3 Symbols in this document	5	10.3.1 Checking the operating pressure	25
2 Safety	5	10.3.2 Monitoring the filter and/or strainer	25
2.1 Proper use	5	10.3.3 Adjusting the overflow valve	26
2.2 Foreseeable misuse	6	10.3.4 Switching off the pump unit	27
2.3 Obligations of the operator-owner	6	10.4 Decommissioning	27
2.4 Safety instructions	6	10.4.1 Decommissioning the pump	27
2.4.1 Fundamental safety instructions	6	10.5 Recommissioning	28
2.4.2 Dangers at magnetic coupling systems	6	10.5.1 Recommissioning the pump	28
3 Identification	7	11 Maintenance	28
3.1 Type code	7	11.1 Dangers during maintenance	28
3.2 Rating plate	8	11.2 Required maintenance	29
4 Technical data	8	11.3 Ball bearing	29
4.1 Operating limits	8	11.4 Maintaining the pump	29
4.2 Required NPSH values	8	11.5 Maintaining the magnetic coupling	30
4.3 Sound pressure level	9	12 Servicing	33
4.4 Weights	9	12.1 Dangers during servicing	33
4.5 Accessories	9	12.2 Wear	34
5 Function description	9	12.2.1 Signs of wear	34
5.1 Pump structure	9	12.2.2 Magnetic coupling	34
5.2 Pump unit structure	10	12.3 Replacing the overflow valve	34
5.3 Functional principle	10	12.3.1 Removing the overflow valve	34
5.4 Magnetic coupling	10	12.3.2 Installing the overflow valve	35
5.5 Housing variants	10	12.4 Replacing the magnetic coupling	35
5.6 Overflow valve	11	12.4.1 Removing the outer rotor	35
6 Transportation, storage	12	12.4.2 Removing the inner rotor	37
6.1 Dangers during transportation	12	12.4.3 Installing the inner rotor	38
6.2 Dangers during storage	12	12.4.4 Installing the outer rotor	39
6.3 Unpacking and checking the state of delivery	12	12.5 Replacing the ball bearing and screw set	41
6.4 Transporting the pump/pump unit	12	12.5.1 Removing the ball bearing and screw set	41
6.5 Storing the pump	13	12.5.2 Installing the ball bearing and screw set	41
7 Preservation	14	13 Disposal	42
7.1 Preservation table	14	13.1 Dismantling and disposing of the pump	42
7.2 Preserving the inner surfaces	14	14 Troubleshooting	43
7.3 Preserving the outer surfaces	15	14.1 Possible faults	43
7.4 Removing the preservation	15	14.2 Troubleshooting	44
8 Installation, removal	16	15 Accessories	46
8.1 Dangers during installation	16	15.1 Heating	46
8.2 Dangers during removing	16	15.1.1 Possible types of heating	46
8.3 Installing the pump	16	15.1.2 Electrical heating system	46
8.4 Removing the pump	17	15.1.3 Fluid heating system	48
9 Connection	18	15.1.4 Heating system special design	49
9.1 Dangers during connection work	18	16 Spare parts	50
9.2 Connecting the pump to the pipe system	18	16.1 Overview	50
9.3 Insulating the pump	19	16.2 Maintenance kits	51
9.4 Connecting the pump unit to the power supply	20	16.2.1 Maintenance kit magnetic coupling KF/ KV 5 – 660	51
10 Operation	20	16.2.2 Maintenance kit magnetic coupling KF/ KV 851 – 1301	52

16.2.3	Maintenance kit magnetic coupling KF/ KV 1500 – 1700	53
16.2.4	Maintenance kit magnetic coupling KF/ KV 2200 – 2900	54
16.2.5	Maintenance kit magnetic coupling KFN/ KFT/KVT	55
16.3	Repair kits	56
16.3.1	Repair kit overflow valve KF/KH/KV 5 – 660 and KFT/KVT/KFN/KFA	56
16.3.2	Repair kit overflow valve KF/KH/KV 851 – 1301	57
16.3.3	Repair kit overflow valve KF/KH/KV 1500 – 1700	58
16.3.4	Repair kit overflow valve KF/KH/KV 2200 – 2900	59
16.3.5	Repair kit, screw set.....	59
16.3.6	Repair kit magnetic coupling.....	60
16.4	Completions	61
16.4.1	Completion Type KF	61
16.4.2	Completion Type KV	62
17	Appendix	63
17.1	Tightening torques for screws with metric screw threads with and without wedge lock washers	63
17.2	Tightening torques for screw plugs with thread measured in inches and elastomer seal	63
17.3	Tightening torques for screws of tensioning elements	64
17.4	Contents of the Declaration of Conformity	64

1 About this document

1.1 General information

1 About this document

1.1 General information

These instructions form part of the product and must be kept for future reference. Furthermore please observe the associated documents.

1.2 Associated documents

- ☐ Declaration of conformity according to EU Directive 2006/42/EC
- ☐ Manufacturer's declaration according to EU Directive 2014/68/EU
- ☐ Data sheet of the pump
- ☐ Technical documentation of the supplied components

1.3 Target groups

The instructions are intended for the following persons:

- ☐ Persons who work with the product
- ☐ Operator-owners who are responsible for the use of the product

Persons who work with the product must be qualified. The qualification ensures that possible dangers and material damage that are connected to the activity are detected and avoided. These persons are qualified personnel who carry out the work properly due to their training, knowledge and experience and on the basis of the relevant provisions.


Information on the required qualification of the personnel is provided separately at the beginning of the individual chapters in these instructions. The following table provides an overview.

Target group	Activity	Qualification
Transport personnel	Transporting, unloading, setting up	Qualified personnel for transport, mobile crane operators, crane operators, forklift operators
Fitter	Mounting, connection	Qualified personnel for mounting
Electrician	Electrical connection	Qualified personnel for electric installation
Trained personnel	Delegated task	Personnel trained by the operator-owner who know the task delegated to them and the possible dangers arising through improper behaviour.








Tab. 1: Target groups

1.4 Symbols





1.4.1 Danger levels

	Signal word	Danger level	Consequences of non-observance
	DANGER	Immediate threat of danger	Serious personal injury, death
	WARNING	Possible threat of danger	Serious personal injury, invalidity
	CAUTION	Potentially dangerous situation	Slight personal injury
	ATTENTION	Potentially dangerous situation	Material damage

1.4.2 Danger signs

	Meaning	Source and possible consequences of non-observance
	Electrical voltage	Electrical voltage causes serious physical injury or death.
	Magnetic field	Magnetic field can cause serious physical injury or death.
	Raised load	Falling objects can result in serious physical injury or death.
	Heavy load	Heavy loads can result in serious back problems.
	Risk of slipping	Discharging pumped liquid and oils on the foundation or tread surfaces can cause falls with serious physical injury or death.
	Flammable substances	Discharging pumped liquid and oils can be easily inflammable and can result in serious burns.
	Hot surface	Hot surfaces of the pump unit can cause burns.

1.4.3 Symbols in this document

	Meaning
	Warning personal injury
	Safety instruction
	Prohibition sign cardiac pacemaker
	Request for action
	Multi-step instructions for actions
	Action result
	Cross-reference

2 Safety

2.1 Proper use

- ☐ Use the pump solely for transporting lubricating liquids that are chemically neutral and that do not contain gas or solid components.
- ☐ Use the pump only within the operating limits specified on the rating plate and in the chapter "Technical data". In the case of operating data that do not agree with the specifications on the rating plate, please contact the manufacturer.
- ☐ The pump is designed specially for the operating pressure named by the customer. If the actual operating pressure deviates notably from this design pressure, damage to the pump can also arise within the specified operating limits. This applies both to notably higher as well as to notably lower operating pressures. Under no circumstances may the minimum pressure lie below 2 bar. In case of any doubt, please contact the manufacturer.

2.2 Foreseeable misuse

- ☐ Any use that extends beyond the proper use or any other use is misuse.
- ☐ The product is not suitable for pumping liquids outside the operational limits.
- ☐ Any bypassing or deactivation of safety equipment during operation is prohibited.

2.3 Obligations of the operator-owner

The operator-owner is the person who operates the product commercially or permits a third party to use it and who bears the legal responsibility for the product, the protection of the personnel and third parties during its operation.

The product is used in industrial applications. The operator-owner is therefore subject to the statutory obligations concerning occupational health and safety.

In addition to the safety instructions in these instructions, the regulations on safety, accident prevention and environmental protection respectively valid for the range of application of the product are to be observed.

2.4 Safety instructions

2.4.1 Fundamental safety instructions



The following safety instructions must be observed strictly:

- ☐ Read these operating instructions carefully and observe them.
- ☐ Read the operating instructions of the components carefully and observe them.
- ☐ Have work only carried out by qualified personnel/trained personnel.
- ☐ Wear personal protective equipment and work carefully.
- ☐ Pumped liquids can be subject to high pressure and can result in personal injury and damage to property in case of incorrect operation or damaged components.
- ☐ Pumped liquids can be hot, poisonous, combustible and caustic. Use corresponding protective equipment.
- ☐ Observe the associated data sheets and safety regulations when handling dangerous materials.
- ☐ Avoid skin contact with system parts carrying liquids at operating temperatures exceeding 60 °C.
- ☐ Collect any discharging pumped liquid safely and dispose of it in an environmentally compatible manner in accordance with the applicable local regulations. Neutralize residues.
- ☐ Keep the mounting surfaces, scaffolding, ladders, lifting platforms and tools clean in order to prevent slipping or stumbling.
- ☐ If pressurized or energized components are damaged, shut down the pump immediately. Replace the components or pump.

2.4.2 Dangers at magnetic coupling systems

Magnetic fields from magnetic coupling systems (MCS) can influence the function and operational safety of electrical and electronic devices. The following safety instructions must be observed.



The following safety instructions must be observed:

- ☐ Keep the MCS away from cardiac pacemakers. There is a danger to life!
 - Under no circumstances may persons with cardiac pacemakers perform installation, dismantling or maintenance work.
- ☐ Persons with cardiac pacemakers must comply with the following safe distances to the MCS:
 - 3 m distance to the openly accessible MCS
 - 1 m distance to pump units with installed MCS
- ☐ Do not bring the MCS in the immediate area of PCs, data carriers and other electronic components.
- ☐ Keep the MCS away from clocks, magnetized tools and measuring equipment as well as all magnetizable parts.
- ☐ Do not bring both the MCS parts together, as this can destroy the magnetic coupling system.

3 Identification

3.1 Type code




Fig. 1: Type code

Item	Classification	Description
1	Type	KF <input type="checkbox"/> Pump with free shaft end <input type="checkbox"/> Pump with inline flanges <input type="checkbox"/> Pump unit with or without pump bracket foot
		KFA <input type="checkbox"/> Pump with free shaft end <input type="checkbox"/> Pump with overhead flanges in special design <input type="checkbox"/> Pump unit with or without pump bracket foot
		KFN <input type="checkbox"/> Pump with free shaft end <input type="checkbox"/> Pump with overhead flanges <input type="checkbox"/> Pump unit with or without pump bracket foot
		KFT <input type="checkbox"/> Pump with free shaft end <input type="checkbox"/> Pump with overhead flanges <input type="checkbox"/> Pump unit with or without pump bracket foot
		KH <input type="checkbox"/> Pump with foot for horizontal mounting <input type="checkbox"/> Pump with inline flanges <input type="checkbox"/> Pump unit on base frame
		KV <input type="checkbox"/> Pump with pedestal for vertical mounting <input type="checkbox"/> Pump with inline flanges for vertical mounting <input type="checkbox"/> Pump unit on pedestal for vertical mounting
		KVT <input type="checkbox"/> Pump with pedestal for vertical mounting <input type="checkbox"/> Pump with overhead flanges PN16 for vertical mounting <input type="checkbox"/> Pump unit on pedestal for vertical mounting
2	Size	Corresponds to delivery rate in [l/min] at 1450 min ⁻¹
3	Shaft seal	A Standard mechanical seal
		B Mechanical seal of hard material
		C Standard radial shaft seal
		D Magnetic coupling
		E Mechanical seal with quench
		F High-temperature radial shaft seal
		X Special design
4	Pressure stage over-flow valve	A Pressure stage 3.0 – 5.9 bar
		B Pressure stage 6.0 – 9.9 bar
		C Pressure stage 10 – 16 bar
		X Special design
5	Heating	A Without heating
		B Electrical heating system
		C Fluid heating system
		X Special design
6	Version index	For internal administration

Tab. 2: Type code

4.3 Sound pressure level

Guide values at 1 m distance, 1450 min⁻¹, 10 bar

	Size									
	5 – 20	32 – 42	55 – 118	160 – 275	370 – 450	550 – 660	851 – 1301	1500 – 1700	2200 – 2900	
	Max. sound pressure level ±3 [dB(A)]									
Pump	56.0	59.0	65.0	71.0	74.0	71.0	76.0	78.5	80.5	
Motor	65.0	66.0	77.0	79.0	79.0	67.0	72.0	76.0	78.0	
Pump unit	66.0	67.0	78.0	80.0	82.0	73.0	78.0	80.5	82.0	

Tab. 4: Sound pressure level

4.4 Weights

The weight is specified on the rating plate.

4.5 Accessories

Note The technical data of the accessories are specified separately ↗ Accessories, Page 46.

5 Function description

5.1 Pump structure




Fig. 3: Pump structure

- 1

Screw plug
- 2

Overflow valve
- 3

Pump housing
- 4

Balancing cylinder
- 5

Ball bearing
- 6

Main screw
- 7

Flange cover
- 8

Vent hole
- 9

Thrust pin
- 10

End cover
- 11

Idle screw

5 Function description

5.2 Pump unit structure

5.2 Pump unit structure




Fig. 4: Pump unit structure - principle diagram

12	Pump	15	Inner rotor
13	Containment can	16	Motor
14	Outer rotor		

5.3 Functional principle

Screw pumps are rotating displacement pumps. The displacement effect results from three rotating screws **6** and **11** and the enclosing pump housing **3**.

Radial support of the screw set is provided through the sliding contact in the pump housing that depends on lubrication by the pumped liquid. Screw pumps are therefore not suitable for dry running and can only be used up to specific pressure limits and viscosity limits. Due to the narrow gap dimensions, suspended solids cannot be pumped.

Axial support of the main screw is effected by a deep-groove ball bearing. In order to reduce the pressure, a balancing cylinder is mounted by the main screw. An integrated overflow valve protects against excessive pressure that could cause housing parts to burst.

The default direction of the rotation of the screw set is clockwise viewed from the motor and is marked on the pump flange by an arrow.


The flow direction is marked on the pump housing by two arrows.



5.4 Magnetic coupling

The shaft end of the pump **12** is enclosed by a containment can **13** that is connected air-tight with the motor-side flange of the pump. Therefore, it is not necessary to seal a rotating free shaft end against a stationary seal housing. Special rotors equipped with powerful permanent magnets are used for transfer of torque from the motor to the pump. The inner rotor **15** is fixed at the shaft end and driven by the outer rotor **14**, which in turn is fixed to the shaft of the motor **16**. The torque is thus transferred contact-free by means of the magnetic field between the outer rotor and inner rotor.

The containment can is made of a non-magnetic material which does not impede the forming of magnetic flux lines between the rotors. The pressure discharge of the containment can is effected via a core drilled hole in the main screw. Therefore, it can be assumed that the pressure in the containment can approximately corresponds to the pressure on the suction side of the pump.


5.5 Housing variants

Housing	Type	Description
	KF/KV	Flange arrangement: Inline flange PN16

Housing	Type	Description
	KFN/KFT/KVT	Flange arrangement: Overhead flange PN6/PN16
	KFA	Flange arrangement: Overhead flange in special design PN16

Tab. 5: Housing variants

5.6 Overflow valve



- 1 Screw plug
- 2 Adjusting screw
- 3 Pressure spring
- 4 Valve body

Fig. 5: Overflow valve

The integrated overflow valve ensures that very high pressures that could result in housing parts bursting do not arise.

The overflow valve is purely there as a safety element for the pump and should not be used for control or regulation purposes such as maintaining pressure. If the valve is kept open for too long under adverse operating conditions (high differential pressures and/or low viscosities) it will only take a few minutes for the overflow valve and the valve seating to become damaged. As a result, the overflow valve will leak permanently and there will be a corresponding reduction in the delivery rate. In addition to this, circulation through the overflow valve for too long results in excess heating of the pump. This reduces viscosity and can ultimately lead to pump failure.

It therefore has to be ensured at the system by a safety valve that the maximum allowable working pressure always lies under the opening pressure of the overflow valve.

Note The opening pressure of the overflow valve is set to 110% of the differential pressure in the factory.

The overflow valve is accessible through a screw plug 1 and can be adjusted from the outside ↴ During operation, Page 25.

- Note**
- ☐ A function test of the overflow valve at least every 5 years is essential for the safe operation ↴ During operation, Page 25.
 - ☐ Scope and if necessary shorter test intervals must be specified by the operator-owner in accordance with the requirements and national provisions (for example Austrian Ordinance of Safety and Health (BetrSichV)).
 - ☐ The first function test must take place directly after the commissioning.
 - ☐ After longer downtimes (> 4 weeks) the function of the overflow valve must be tested again.

6 Transportation, storage

6.1 Dangers during transportation



The following safety instructions must be observed:

- ☐ Have all work only carried out by authorized transport personnel.
- ☐ Use intact and correctly dimensioned hoisting equipment.
- ☐ Ensure that the means of transport is in a flawless state.
- ☐ Ensure that the centre of gravity of the load is taken into consideration.
- ☐ Do not stand under raised loads.

6.2 Dangers during storage



The following safety instructions must be observed:

- ☐ Observe the storage conditions.

6.3 Unpacking and checking the state of delivery

Personnel qualification:	<input type="checkbox"/> Trained personnel
--------------------------	--



⚠ DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.

1. ► Upon delivery check the pump/pump unit for damage during transportation.
2. ► Report damage during transportation immediately to the manufacturer.
3. ► Dispose of packaging material in accordance with the locally applicable regulations.

6.4 Transporting the pump/pump unit

Personnel qualification:	<input type="checkbox"/> Transport personnel
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective helmet <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Mobile crane, forklift, hoisting equipment



⚠ DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.



WARNING

Risk of injury and damage to equipment through falling and toppling parts.

- ▶ Use intact and correctly dimensioned hoisting equipment in accordance with the total weight to be transported.
- ▶ Select the lift points for the hoisting equipment in accordance with the centre of gravity and the weight distribution.
- ▶ Use at least two load ropes.
- ▶ In the case of vertical transportation secure the motor against tipping.
- ▶ Do not stand under raised loads.

ATTENTION

Damage to equipment through improper transportation.

- ▶ Protect the pump against damage, heat, sunlight, dust and moisture.




Fig. 6: Fastening of hoisting equipment - principle diagrams

1. ▶ Attach the hoisting equipment to the pump/pump unit and tighten. Ensure that the centre of gravity lies exactly under the crane hook.
2. ▶ Lift the pump/pump unit carefully and put it down shock-free.
3. ▶ Before loosening the transport belts ensure that the pump/pump unit is secured against tilting.

6.5 Storing the pump

During the test run, the internal components of the pump are wetted with test oil, which has a preservative effect. Pressure connection and suction connection are closed with protective caps. Unless otherwise specified, the outer surfaces of the pump are preserved with a single-coat PU-based two-component paint.

The preservative applied at the factory will protect the pump for about six weeks, if it is stored in a dry and clean location.

The manufacturer offers a long-term preservation for storage times of up to 60 months. The pump is additionally packed in hermetically sealing anti-corrosion paper.

Personnel qualification:	<input type="checkbox"/> Transport personnel
Aids:	<input type="checkbox"/> Mobile crane, forklift, hoisting equipment



DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.

7 Preservation

7.1 Preservation table

ATTENTION

Damage to equipment and corrosion if stored improperly and during longer standstills.

- ▶ Protect the pump against damage, heat, sunlight, dust and moisture.
- ▶ Protect against corrosion during longer standstill.
- ▶ Observe measures for storing and preservation.

1. ▶ Store cool and dry and protect against sunlight.
2. ▶ Ensure that the anti-corrosion paper is not damaged.
3. ▶ Observe the intervals for preservation ↗ Preservation, Page 14.

7 Preservation

7.1 Preservation table

Preservation has to be carried out additionally under the following conditions:

Type of delivery	Condition
Standard delivery	<input type="checkbox"/> Storage time exceeding six weeks <input type="checkbox"/> Unfavourable storage conditions such as high humidity, salty air, etc.
Delivery with long-term preservation	<input type="checkbox"/> Opened or damaged packaging

Tab. 6: Conditions for additional preservation

7.2 Preserving the inner surfaces

Personnel qualification:	<input type="checkbox"/> Trained personnel
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Preservative (acid-free and resin-free oil)



DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.

1. ▶ Open the packaging carefully. If the pump is protected additionally by anti-corrosion paper, ensure that it is not damaged.
2. ▶ Close the suction connection of the pump with a blind flange.
3. ▶ Pour the preservative into the pressure connection until it reaches approx. 2 cm under the rim, while slowly turning the main screw against the direction of rotation.
4. ▶ Close the pressure connection of the pump with a new blind flange.
5. ▶ Close the packaging carefully.
6. ▶ After about six months storage check the filling level of the preservative and if necessary top up.

7.3 Preserving the outer surfaces

Personnel qualification:	<input type="checkbox"/> Trained personnel
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Face protection <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Calcium complex grease (for example TEVIER® GREASE WAVE 100 with adhesive additive) <input type="checkbox"/> Castrol Rustilo DWX 33 or other preservative offering comparable protection

**⚠ DANGER****Magnetic field.**

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.

1. ➤ Brush calcium complex grease corrosion protection (for example TEVIER® FETT WAVE 100 with adhesive additive) to the mounting surfaces.
2. ➤ Brush or spray preservative (for example Castrol Rustilo DWX 33) onto the process connections and remaining plain and unpainted parts.
3. ➤ At intervals of about six months check the preservation and if necessary repeat.

7.4 Removing the preservation

Personnel qualification:	<input type="checkbox"/> Trained personnel
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Face protection <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Solvent <input type="checkbox"/> Collection tank <input type="checkbox"/> Steam-jet cleaning device with wax-dissolving additives

**⚠ DANGER****Magnetic field.**

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.

**⚠ CAUTION****Risk of injury through discharging preservative.**

- ▶ Wear personal protective equipment during all the work.
- ▶ Collect any discharging preservative safely and dispose of it in an environmentally compatible manner in accordance with the applicable local regulations.

1. ➤ Clean the outside of the pump with solvents, if necessary using a steam-jet cleaning device.
2. ➤ Remove the pressure-side blind flange carefully in order to reduce any pressure that may exist in the pump.
3. ➤ Drain the pump, collecting the preservative in a suitable vessel.
4. ➤ Remove the blind flange on the suction side.
5. ➤ To remove the residual preservative, flush the pump with the pumped liquid.

8 Installation, removal

8.1 Dangers during installation



The following safety instructions must be observed strictly:

- ☐ Have all work carried out only by authorized qualified personnel.
- ☐ Before installation ensure that the operating limits, NPSH values and ambient conditions are observed.
- ☐ Observe the tightening torques ↗ Appendix, Page 63.
- ☐ Ensure that all the components can be accessed and that maintenance work can be carried out easily.

8.2 Dangers during removing



The following safety instructions must be observed strictly:

- ☐ Have all work carried out only by authorized qualified personnel.
- ☐ Before beginning work, let the pump unit cool down to the ambient temperature.
- ☐ Collect any discharging pumped liquid safely and dispose of it in an environmentally compatible manner in accordance with the applicable local regulations.
- ☐ Ensure that the collection tank for discharging pumped liquid is sufficiently large.

8.3 Installing the pump

The pumps can be operated in horizontal and vertical installation position.

Note Soiling in the pipe system impair the service life of the pump. If the pipe system is flushed using the pump during the initial commissioning, an additional commissioning filter has to be installed temporarily before the pump at the system (mesh width: 0.02 mm).

Personnel qualification:	<input type="checkbox"/> Transport personnel <input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective helmet <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Mobile crane, forklift, hoisting equipment



⚠ DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.



⚠ WARNING

Risk of injury and damage to equipment through falling and toppling parts.

- ▶ Only fasten the pump on a stable load-bearing underground or stable load-bearing load support.
- ▶ Ensure that fastening elements and pipings are fastened sufficiently.


ATTENTION

Damage to motor through discharging pumped liquid.

- ▶ Do not install the pump above the motor.

ATTENTION**Damage to device through impurity in the pipe system.**

- ▶ During welding work attach protective covers in front of the connecting flanges.
- ▶ Ensure when welding that welding beads and abrasive dust cannot get into the pipe system and the pump.
- ▶ Ensure that a commissioning filter is installed when the pipe system is flushed and cleaned using the pump.



- 1 Pressure connection
2 Suction connection

Fig. 7: Flow direction

Requirement:

- ✓ Pump protection: Integrated overflow valve or system-side overflow valve/safety valve installed.
 - ✓ Pump connections protected against soiling, for example by using the protective cover mounted in the factory
 - ✓ If required, hoisting equipment prepared
1. ▶ Bring the pump in the installation position, while observing the position of the motor and the arrows for the flow direction on the pump housing (1 pressure connection, 2 suction connection).
 2. ▶ Fasten the pump with fastening elements securely on the underground.

8.4 Removing the pump

Personnel qualification:	<input type="checkbox"/> Transport personnel <input type="checkbox"/> Fitter <input type="checkbox"/> Electrician
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective helmet <input type="checkbox"/> Face protection <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Mobile crane, forklift, hoisting equipment <input type="checkbox"/> Collection tank

**⚠ DANGER****Risk of death resulting from electric shock.**

- ▶ Ensure that the electrical power supply is de-energized and is secured against being switched back on.
- ▶ Observe the operating instructions of the electrical components.

**⚠ DANGER****Magnetic field.**

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.

9 Connection

9.1 Dangers during connection work



DANGER

Risk of death through emitted pumped liquid.

Pumped liquids can be hot, poisonous, combustible and caustic and can spray out under high pressure.

- ▶ Wear personal protective clothing during all the work. Ensure face protection.
- ▶ Before beginning work, let the pump unit cool down to the ambient temperature.
- ▶ Ensure that the pump is depressurized.
- ▶ Collect any discharging pumped liquid safely and dispose of it in an environmentally compatible manner in accordance with the applicable local regulations.

Requirement:

- ✓ Pump unit cooled down to the ambient temperature
 - ✓ Pump unit disconnected from the electrical power supply, deenergized and secured against being switched back on
1. ▶ Close the pressure-side and suction-side shut-off devices.
 2. ▶ Empty the pump at the lowest point. Collect the discharging pumped liquid in a collection tank.
 3. ▶ Dismantle the pressure-side and suction-side connecting flanges.
 4. ▶ Disconnect the pump unit from the pipe system and empty it. Collect any discharging pumped liquid.
 5. ▶ Screw out the fastening elements used to fasten the pump.
 6. ▶ Dismantle the pump unit on site or transport it to a suitable location ↗ Transportation, storage, Page 12.

9 Connection

9.1 Dangers during connection work



The following safety instructions must be observed strictly:

- ☐ Have all work on the pump and pipe system only carried out by authorized qualified personnel.
- ☐ Ensure that impurities cannot get into the pump and pipe system.
- ☐ Ensure that mechanical connections are mounted stress-free.
- ☐ Observe the tightening torques ↗ Appendix, Page 63.
- ☐ Have all the work on the electrical equipment only carried out by electricians.
- ☐ Before beginning work on the pump ensure that the electrical power supply is deenergized and is secured against being switched back on.
- ☐ If the insulation of the electrical cables or wires is damaged, disconnect the power supply immediately.

9.2 Connecting the pump to the pipe system

Personnel qualification:	<input type="checkbox"/> Transport personnel <input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective gloves <input type="checkbox"/> Protective helmet <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Mobile crane, forklift, hoisting equipment



DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.

ATTENTION

Damage to device through impurity in the pipe system.

- ▶ During welding work attach protective covers in front of the connecting flanges.
- ▶ Ensure when welding that welding beads and abrasive dust cannot get into the pipe system and the pump.
- ▶ Ensure that a commissioning filter is installed when the pipe system is flushed and cleaned using the pump.

ATTENTION

Damage to device through mechanical stress.

- ▶ Ensure that the pump is mounted free of mechanical stresses in the pipe system.
- ▶ Observe the tightening torques.




Fig. 8: Connection to pipe system

1. ➤ Turn the pump shaft or the fan impeller of the motor. This tests that the pump runs smoothly. If the pump shaft cannot be turned by hand, remedy the fault before installing the pump ↪ Troubleshooting, Page 43.
2. ➤ Before carrying out welding work mount a protective cover on the suction connection and pressure connection.
3. ➤ Place the piping in position and support the weight of the piping.
4. ➤ Check the linear, height and angular offset and correct if necessary.
⇒ If the screws tighten easily, this is a sure sign that the installation is stress-free.
5. ➤ Tighten the connecting screws crosswise with torque, Table of tightening torques ↪ Appendix, Page 63.

9.3 Insulating the pump

Personnel qualification:	<input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Insulation material



⚠ DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump station.



⚠ WARNING

Hot surface.

Touching of uninsulated hot surfaces results in burns.

- ▶ Insulate components and pipings in which hot liquids (> 60 °C) flow before commissioning.

- ➤ Before commissioning, carefully insulate all potentially hot surfaces of the pump and the connected piping or provide suitable protection against accidental contact.

10 Operation

9.4 Connecting the pump unit to the power supply

9.4 Connecting the pump unit to the power supply

Personnel qualification:	<input type="checkbox"/> Electrician
Aids:	<input type="checkbox"/> Operating instructions of the motor <input type="checkbox"/> Motor circuit diagram



DANGER

Risk of death resulting from electric shock.

- ▶ Ensure that the electrical power supply is de-energized and is secured against being switched back on.
- ▶ Before commissioning ensure correct grounding and equipotential bonding.
- ▶ Observe the operating instructions of the electrical components.



DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.

1. ➤ Ensure that the operating data on the rating plate of the motor agree with the operating data of the pump and with the local power supply.
2. ➤ Carefully earth the pump bracket foot, base frame or pedestal via the screwing.
3. ➤ Connect the motor in accordance with the operating instructions and circuit diagram in the motor terminal block.
4. ➤ When connecting the pump unit to the complete system continue equipotential bonding.

10 Operation

10.1 Dangers during operation



The following safety instructions must be observed strictly:

- ☐ Have all work carried out only by authorized qualified personnel.
- ☐ Before commissioning ensure that a safety valve has been installed in the pipe system on the pressure side before the first shut-off device.
- ☐ Before commissioning, make sure that the suction line and pump are filled.
- ☐ Pumped liquids can be hot, poisonous, combustible and caustic. Use corresponding protective equipment.
- ☐ Ensure that the pump station is only operated within the operating limits.
- ☐ Wear hearing protection if you work for a longer time directly at the pump.
- ☐ Ensure that the maximum permissible system pressure is not exceeded.
- ☐ Ensure that during cooling down or heating up the pump is only subjected to slow temperature changes.
- ☐ Ensure that existing safety equipment is not bypassed or activated during operation.
- ☐ Before decommissioning ensure that the electrical power supply is deenergized and is secured against being switched back on.

10.2 Commissioning

10.2.1 Cleaning the pipe system

Note Soiling in the pipe system impair the service life of the pump. If the pipe system is flushed using the pump during the initial commissioning, an additional commissioning filter has to be installed temporarily before the pump at the system.

Personnel qualification:	<input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots



DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump station.

ATTENTION

Damage to equipment through additional pressure loss in the commissioning filter/commissioning strainer.

- ▶ Calculate the flow resistance and determine the remaining pump intake.
- ▶ Monitor the suction-side pressure.
- ▶ Check the commissioning filter/commissioning strainer regularly.

Requirement:

✓ If required, commissioning filter installed (mesh width 0.02 mm)

1. ▶ Clean the complete pipe system before commissioning in order to protect the pump.
2. ▶ Flush the pipe system at least 50 – 100 hours.

10.2.2 Filling and venting the pump

Possibilities

There are two possible ways to fill the pump:

- ☐ Via the suction connection or pressure connection
- ☐ Via the vent holes

Filling and venting the pump via the suction connection or pressure connection

Personnel qualification:	<input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Face protection <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots



DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.




⚠ DANGER

Risk of death through discharging pumped liquid.

Pumped liquids can be hot, poisonous, combustible and caustic and can spray out under high pressure.

- ▶ Wear personal protective equipment during all the work. Ensure face protection.
- ▶ Collect any discharging pumped liquid safely and dispose of it in an environmentally compatible manner in accordance with the applicable local regulations.



1 Sealing chamber vent hole

1. ▶ Open the screw plug of the vent hole **1** by a maximum of 2 rotations so that air can escape during the filling process.
2. ▶ Open the suction-side or pressure-side shut-off device and fill the pump via the suction connection or pressure connection until pumped liquid is emitted at the vent hole **1**.
3. ▶ While filling, turn the pump shaft or the motor fan impeller manually in order to speed up the filling process:
 Filling via suction connection: Turn the pump shaft in the direction of the arrow on the pump flange.
 Filling via pressure connection: Turn the pump shaft against the direction of the arrow on the pump flange.
4. ▶ Retighten the screw plug of the vent hole **1**.

Filling and venting the pump via the vent hole

Personnel qualification:	<input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Face protection <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots



⚠ DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.




⚠ WARNING

Risk of injury through emitted pumped liquid.

Pumped liquids can be hot, poisonous, combustible and caustic.

- ▶ Wear personal protective clothing during all the work. Ensure face protection.
- ▶ Collect any discharging pumped liquid safely and dispose of it in an environmentally compatible manner in accordance with the applicable local regulations.



- 1 Sealing chamber vent hole
- 2 Suction-side vent hole
- 3 Pressure-side vent hole

Requirement:

✓ Shut-off devices in the suction line and pressure line closed

1. ➤ Remove the screw plug of the vent hole 1 so that the air can escape during the filling process.
2. ➤ Remove the screw plug of the pressure-side vent hole 3.
3. ➤ Fill the pump via the pressure-side vent hole 3 until the pumped liquid is emitted from the vent hole 1.
4. ➤ While filling, turn the pump shaft or the motor fan impeller manually in order to speed up the filling process:
Filling the suction chamber: Turn the pump shaft against the direction of the arrow on the pump flange.
Filling the sealing chamber: Turn the pump shaft in the direction of the arrow on the pump flange.
To speed up the filling of the sealing chamber, fill the sealing chamber of the pump via the vent hole 1 until pumped liquid is emitted.
5. ➤ Retighten the screw plug of the pressure-side vent hole 3.
6. ➤ Retighten the screw plug of the vent hole 1.

10.2.3 Checking the direction of rotation

The direction of rotation is indicated by an arrow on the pump flange/pump housing. The direction of rotation of the motor specifies the direction of rotation of the pump. The fan impeller of the motor must rotate in the same direction in which the arrow for the direction of rotation on the pump flange points.

Note Standard direction of rotation: clockwise (viewed from the motor)

Personnel qualification:	<input type="checkbox"/> Fitter
--------------------------	---------------------------------



⚠ DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.


- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.

ATTENTION

Dry running can damage pump equipment.

- ▶ Ensure that the pump is filled properly.
- ▶ Switch the pump on for a maximum of one second and then off again immediately.

1. ➤ Switch on the power supply and then turn it off again immediately.



2. ➤ Compare the direction of rotation of the fan impeller with the arrow for the direction of rotation 1.
3. ➤ If the directions do not match, swap the two electrical connection phases. Repeat Steps 1 and 2.

10.2.4 Commissioning the pump

Personnel qualification:	<input type="checkbox"/> Fitter <input type="checkbox"/> Electrician
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Face protection <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Collection tank



⚠ DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.



⚠ DANGER

Risk of death resulting from bursting components and discharging pumped liquid.

As a result of impermissibly high pressure, components can burst with high energy, for example through the pressure-side pipe system being shut off.

- Wear personal protective equipment during all the work.
- System protection: Before carrying out commissioning ensure that a safety valve is installed in the pressure-side pipe system at the system end.
- Pump protection: Ensure before commissioning that an integrated overflow valve or system-side overflow valve/safety valve is installed.



⚠ WARNING

Risk of injury through emitted pumped liquid.

Pumped liquids can be hot, poisonous, combustible and caustic.

- Wear personal protective clothing during all the work. Ensure face protection.
- Collect any discharging pumped liquid safely and dispose of it in an environmentally compatible manner in accordance with the applicable local regulations.



⚠ WARNING

Hot surface.

Touching of uninsulated hot surfaces results in burns.

- Insulate components and pipings in which hot liquids (> 60 °C) flow before commissioning.



⚠ WARNING

Risk of injury through emitted pumped liquid.

Bursting of the containment can due to damage by iron particles in the medium.

- Install filter/strainer with magnetic separator on suction side.

ATTENTION

Dry running can damage pump equipment.

- Ensure that the pump and the connected pipe system are filled properly.
- If the pump does not deliver after 10 – 15 seconds, abort commissioning.

Requirement:

- ✓ Pump unit set up correctly
- ✓ Connections connected sealingly
- ✓ Motor connected correctly
- ✓ Pipe system is free of impurities
- ✓ System protection: Safety valve in accordance with EN ISO 4126-1 installed in the pressure-side pipe system before the first shut-off device
- ✓ Pump protection: Integrated overflow valve or system-side overflow valve/safety valve installed.
- ✓ Filter/strainer with magnetic separator installed on suction side
- ✓ Pump filled with pumped liquid
- ✓ Shut-off devices in the suction line and pressure line opened

1. ➤ Switch on the pump unit.
⇒ The pump delivers when the pressure on the pressure side of the pump rises or a flow indicator at the system side triggers.
2. ➤ If the pump does not deliver after 10 – 15 seconds of operation, abort commissioning. Eliminate the cause of the fault and only then continue with commissioning. Take the information from the troubleshooting table into account ➤ Troubleshooting, Page 43.
3. ➤ Run the pump for a few minutes to allow the pipe system to vent fully.
⇒ The pipe system is fully vented when the pump operating noise is smooth and a pressure gauge on the pressure side shows no more fluctuations.
4. ➤ Checking overflow valve functions ➤ During operation, Page 25.

10.3 During operation

10.3.1 Checking the operating pressure

Personnel qualification: ☐ Trained personnel




Fig. 9: Pressure gauge shut-off valves closed/open - principle diagram



⚠ DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump station.

ATTENTION

Leak in the pressure gauge through permanently opened pressure gauge shut-off valve.

- ▶ Close the pressure gauge shut-off valve immediately after completing reading.

1. ➤ Open the pressure gauge shut-off valve.
2. ➤ Read the operating pressure and close the pressure gauge shut-off valve.

10.3.2 Monitoring the filter and/or strainer

Note The manufacturer recommends protecting the pump against soiling by means of a filter and/or strainer installed at the system end (mesh width 0.5 mm). The degree of soiling of the filter and/or the strainer can be monitored by means of a suction-side pressure gauge or a differential pressure indicator.

Personnel qualification: ☐ Trained personnel



⚠ DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump station.



⚠ WARNING

Risk of injury through emitted pumped liquid.

Bursting of the containment can due to damage by iron particles in the medium.

- Install filter/strainer with magnetic separator on suction side.

1. ► After commissioning monitor the degree of soiling of the filter and/or strainer by means of a suction-side pressure gauge or a differential pressure indication.
2. ► Also check the filters/strainers in the event of a pressure drop on the suction side. Observe the dimensioning data of the manufacturer of the filters and/or strainers.
3. ► Check the suction-side pressure every two weeks during operation.
4. ► Regularly check the magnetic separator in the filter/strainer during operation and clean it if necessary.

10.3.3 Adjusting the overflow valve

Personnel qualification:	<input type="checkbox"/> Fitter
Aids:	<input type="checkbox"/> Allen key

Note The opening pressure of the overflow valve is set to 110% of the differential pressure in the factory.




Fig. 10: Overflow valve



⚠ WARNING

Risk of injury through emitted pumped liquid.

Pumped liquids can be hot, poisonous, combustible and caustic.

- Wear personal protective clothing during all the work. Ensure face protection.
- Collect any discharging pumped liquid safely and dispose of it in an environmentally compatible manner in accordance with the applicable local regulations.

Requirement:

- ✓ Pressure-side pressure gauge installed

1. ► Switch on the pump unit and remove the screw plug **1** of the overflow valve.
2. ► Increase the supply pressure step-by-step to check the opening pressure of the overflow valve. Keep an eye on the pressure gauge and make sure that the operating limits are observed.
 - ⇒ The opening pressure is reached, when the displayed pressure falls.

3. ➤ Turn the adjusting screw **2** to set the opening pressure:
Turning clockwise: Increase the opening pressure
Turning counter-clockwise: Reduce the opening pressure
4. ➤ Repeat Steps 2 and 3 until the desired opening pressure is reached.
5. ➤ Tighten the screw plug **1** again.

10.3.4 Switching off the pump unit

Personnel qualification:	<input type="checkbox"/> Trained personnel
--------------------------	--

ATTENTION

Seal damage through pressurizing during standstill.

- ▶ Ensure that the maximum permissible system pressure is not exceeded.

1. ➤ Switch off the motor.
2. ➤ Close the pressure-side shut-off device.

10.4 Decommissioning

10.4.1 Decommissioning the pump

Decommissioning is an operation interruption that requires different measures depending on the scope and duration of the interruption as well as the properties of the pumped liquid.

Personnel qualification:	<input type="checkbox"/> Fitter <input type="checkbox"/> Electrician
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Collection tank



DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.



WARNING

Risk of injury through emitted pumped liquid.

Pumped liquids can be hot, poisonous, combustible and caustic.

- ▶ Wear personal protective clothing during all the work. Ensure face protection.
- ▶ Collect any discharging pumped liquid safely and dispose of it in an environmentally compatible manner in accordance with the applicable local regulations.

ATTENTION

Damage to equipment through excessively fast temperature change.

- ▶ Subject the pump only to slow temperature changes.
- ▶ Under no circumstances heat the pump with an open flame.

➤ Carry out the following measures during operation interruptions:

11 Maintenance

10.5 Recommissioning

Scope of the operation interruption	Measure
<input type="checkbox"/> Shutting down the pump for a longer period	—> Depending on the pumped liquid
<input type="checkbox"/> Draining the pump	—> Close the pressure-side and suction-side shut-off devices.
<input type="checkbox"/> Dismantling the pump	—> Disconnect the motors from the power supply and secure against being switched back on.
<input type="checkbox"/> Storing the pump	—> Observe measures for storing and preservation ↳ Transportation, storage, Page 12.

Tab. 7: Measures during operation interruptions

Behaviour of the pumped liquid	Duration of the operation interruption	
	Short	Long
<input type="checkbox"/> Solids sediment	—> Rinse the pump.	—> Rinse the pump.
<input type="checkbox"/> Congealed/frozen <input type="checkbox"/> No corrosive burden	—> Heat or drain the pump.	—> Drain the pump.
<input type="checkbox"/> Congealed/frozen <input type="checkbox"/> Corrosive burden	—> Heat or drain the pump.	1. —> Drain the pump. 2. —> Preserve the pump.
<input type="checkbox"/> Remains liquid <input type="checkbox"/> No corrosive burden	—	—
<input type="checkbox"/> Remains liquid <input type="checkbox"/> Corrosive burden	—	1. —> Drain the pump. 2. —> Preserve the pump.

Tab. 8: Measures depending on the behaviour of the pumped liquid

—> Drain the pump via the pressure line, suction line, vent screws and screw plugs.

10.5 Recommissioning

10.5.1 Recommissioning the pump

—> Depending on the extent and duration of the interruption of operation, carry out steps as for commissioning ↳ Commissioning, Page 21.

11 Maintenance

11.1 Dangers during maintenance



The following safety instructions must be observed strictly:

- ☐ Have all work carried out only by authorized qualified personnel.
- ☐ Before beginning work, let the pump unit cool down slowly to the ambient temperature. Avoid rapid temperature changes.
- ☐ Pumped liquids can be hot, poisonous, combustible and caustic. Use corresponding protective equipment.
- ☐ Collect any discharging pumped liquid safely and dispose of it in an environmentally compatible manner in accordance with the applicable local regulations.
- ☐ Ensure that the collection tank for discharging pumped liquid is sufficiently large.
- ☐ Observe the operating instructions and data sheets of the components.

11.2 Required maintenance

The service life depends on the observance of the operating conditions of the pump and the requirements from the operating instructions of the components.

Component	Required maintenance	Cycle
Filter/strainer with magnetic separator	<input type="checkbox"/> Cleaning the magnetic separator	Depending on the pumped liquid
Filter/strainer (system side)	<input type="checkbox"/> Check of the suction-side pressure	2 weeks
Magnetic coupling	<input type="checkbox"/> Checking the tightening torques <input type="checkbox"/> Checking the inside of the containment can for wear/scoring <input type="checkbox"/> Check for accumulated iron particles on the inner rotor <input type="checkbox"/> Check for accumulated iron particles on the outer rotor	1 year
Overflow valve	<input type="checkbox"/> Function test	≤ 5 years

Tab. 9: Required maintenance

11.3 Ball bearing

When using the pump in lubrication oil applications with a minimum purity class of 21/18/13 according to ISO 4406, a bearings replacement at the latest after 5 years (40000 h) is sufficient.

11.4 Maintaining the pump

Personnel qualification:	<input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots <input type="checkbox"/> Face protection



⚠ DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.



⚠ WARNING

Risk of injury through emitted pumped liquid.

Pumped liquids can be hot, poisonous, combustible and caustic.

- Wear personal protective clothing during all the work. Ensure face protection.
- Collect any discharging pumped liquid safely and dispose of it in an environmentally compatible manner in accordance with the applicable local regulations.

1. ► Check the pump visually and acoustically every four weeks.
2. ► If there are signs of wear, eliminate the cause ➔ Servicing, Page 33.

11.5 Maintaining the magnetic coupling

Personnel qualification:	<input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots <input type="checkbox"/> Face protection



⚠ DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.



⚠ WARNING


Hot surface.

Components of the magnetic coupling heat up more than the pump during operation. Touching the magnetic coupling will result in burns.

- Before working on the magnetic coupling, allow the pump including the magnetic coupling to cool down to ambient temperature.
- Wear personal protective equipment at all times during operation. Be sure to wear protective gloves.


1. Check tightening torques of parts of the magnetic coupling annually in accordance with the table below. See also replacing the magnetic coupling ↪ Servicing, Page 33, tightening torques to be observed ↪ Appendix, Page 63.
2. Carefully clean outer surfaces of the inner rotor, outer rotor and containment can from metallic solids and other adherences ↪ Servicing, Page 33.
3. Check axial play of the ball bearing through manual movement of the shaft, see below. Replace in case of an noticeable play of more than 0.5 mm ball bearing ↪ Servicing, Page 33.

Check tightening torques



Item No.	Part
1	Tensioning element
2*	Threaded pin outer rotor support
3*	Countersunk screw outer rotor support
4	Socket screws pump bracket – pump
5	Socket screws outer rotor support – outer rotor
6	Socket screws containment can – pump
*	Depending on motor size

Tab. 10: Magnetic coupling: Parts to be maintained

Check inner rotor, outer rotor and containment can

1. ➤ Check containment can (green) 1 inside and outside for scratches, scores or other damage.
2. ➤ Check the inner rotor and the inside of the outer rotor 2 for cleanliness (no particles or chips) and damage.
3. ➤ Clean all surfaces completely of solids or ferrous build-up, see below.



Fig. 11: Containment can
Left: Outer surface free from grooves
Right: Inside free from grooves

11 Maintenance

11.5 Maintaining the magnetic coupling



Fig. 12: Containment can
Left: Groove extends over the entire wall thickness
Right: several deep grooves in succession

4. ➤ Containment can
Check the condition of the can, especially the inside.
⇒ If the grooves are deeper than 0.5 mm, the containment can must be replaced, as the compressive strength of the thin-walled containment can may be considerably reduced.



Fig. 13: Inner rotor
Left: Inner rotor without adhesions
Right: Large amount of iron particles accumulated on the inner rotor


5. ➤ Inner rotor
If iron particles adhere to the surface, degrease the inner rotor with a solvent (acetone) and compressed air to remove the particles. Wipe off any remaining particles with a clean cloth over the edge of the inner rotor.

Check ball bearing**Fig. 14: Bearing**

Left: Worn bearing with missing cage and several rolling elements

Right: running surface of bearing inner ring with embedded deposits

1. ➔ Check the condition of the bearing for completeness of the rolling elements and their surface condition.
2. ➔ Check bearing clearance and condition of bearing cage.

**Fig. 15: Bearing clearance**

- ⇒ The ball bearing must be replaced when the limits of the radial and axial play (bearing clearance) are exceeded.

The limits of the radial bearing clearance for non-installed bearings are specified in DIN 620-4 or ISO 5753-1. The limits of the axial bearing clearance depend on the radial bearing clearance and the concrete installation conditions so that no generally valid limits can be specified for this.

The value of 0.5 mm specified above is an empirical value tested in practice.

12 Servicing**12.1 Dangers during servicing****The following safety instructions must be observed strictly:**

- ☐ Have all work carried out only by authorized qualified personnel.
- ☐ Before beginning work on the pump ensure that the electrical power supply is deenergized and is secured against being switched back on.
- ☐ Before beginning work, let the pump unit cool down slowly to the ambient temperature. Avoid rapid temperature changes.
- ☐ Pumped liquids can be hot, poisonous, combustible and caustic. Use corresponding protective equipment.
- ☐ Ensure that the pump is depressurized and that shut-off devices are not operated uncontrolled.
- ☐ Collect any discharging pumped liquid safely and dispose of it in an environmentally compatible manner in accordance with the applicable local regulations.
- ☐ Ensure that the collection tank for discharging pumped liquid is sufficiently large.
- ☐ Observe the tightening torques ↻ Appendix, Page 63.
- ☐ Observe the operating instructions and data sheets of the components.

12.2 Wear

12.2.1 Signs of wear

The following table lists signs of progressive wear of individual pump elements:

Finding	Cause	Elimination
Increased running noises	Incipient damage to bearing	➔ Replace the ball bearing.
Reduction in the delivery rate or pressure under constant operating conditions	Advanced wear of screws and housing	➔ Replace the pump.

Tab. 11: Signs of wear

12.2.2 Magnetic coupling

When using the pump in lubrication oil applications with a minimum purity class of 21/18/13 according to ISO 4406, an inspection at the latest after 5 years (40000 h) is sufficient.

Especially for pump systems where the containment can is exposed to an inlet pressure > 0.5 barg (14.5 psig), in combination with the risk of iron particles in the lubricating oil system and no possibility of fine filtration directly upstream of the pump, we strongly recommend an annual inspection.


Magnetic filter systems

If iron particles accumulate and deposit on the inner rotor and containment can, regular inspection and cleaning of the magnetic coupling is required. In this case, the manufacturer recommends installing a filter/strainer with magnetic separator or a similar device to catch ferrous particles upstream of the pump.

12.3 Replacing the overflow valve

12.3.1 Removing the overflow valve


Personnel qualification:	<input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots



1. ➔ Remove the screw plug **1** and socket screws **2**.
2. ➔ Remove the end cover **3** and flat gasket **4** from the pump housing **5**.
3. ➔ Carefully screw out the adjusting screw **8** and remove the pressure spring **7** and valve body **6** from the pump housing.

12.3.2 Installing the overflow valve

Personnel qualification:	<input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots



1. ➤ Clean the fitting surface carefully and bond a new flat gasket **4** to the fitting surface.
2. ➤ Insert the valve body **6**, pressure spring **7** into the pump housing **5** and secure the pressure spring with the adjusting screw **8**.
3. ➤ Position the end cover **3** and tighten the socket screws **2** with torque.
4. ➤ Set the overflow valve ⚠ During operation, Page 25.

12.4 Replacing the magnetic coupling

12.4.1 Removing the outer rotor

Personnel qualification:	<input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Open-end spanner <input type="checkbox"/> Mounting lever <input type="checkbox"/> Hoisting equipment <input type="checkbox"/> Positive guide

**! DANGER****Magnetic field.**

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.

**! WARNING****Risk of injury and damage to equipment through falling and toppling parts.**

- ▶ Use intact and correctly dimensioned hoisting equipment in accordance with the total weight to be transported.
- ▶ Select the lift points for the hoisting equipment in accordance with the centre of gravity and the weight distribution.
- ▶ Use at least two load ropes.
- ▶ In the case of vertical transportation secure the motor against tipping.
- ▶ Do not stand under raised loads.



WARNING

Danger of crushing between motor and pump.

When dismantling/assembling the motor with the pump, the strong magnetic forces can cause sudden collision and therefore injuries to hands or fingers.

- ▶ Use positive guide for disassembly/assembly.
- ▶ Two people are required.
- ▶ Use suitable hoisting equipment (for example chain hoist).
- ▶ Carry out disassembly/assembly in a vertical position if possible.
- ▶ Fix the pump with suitable measures.
- ▶ When the motor is disassembled/assembled, ensure that hands/fingers are not positioned between motor and pump.





WARNING


Hot surface.


Components of the magnetic coupling heat up more than the pump during operation. Touching the magnetic coupling will result in burns.

- ▶ Before working on the magnetic coupling, allow the pump including the magnetic coupling to cool down to ambient temperature.
- ▶ Wear personal protective equipment at all times during operation. Be sure to wear protective gloves.

Requirement:

- ✓ Pump unit disconnected from the electrical power supply, deenergized and secured against being switched back on
1.  Before dismantling, close the suction connection and pressure connection of the pump with protective covers.
 2.  Fix the pump unit with suitable means so that the pump cannot tilt after dismantling the motor.





3. ➤ Attach the hoisting equipment to the motor 2.
4. ➤ Loosen cap screws between motor and pump bracket 3 and replace with positive guide 30.
5. ➤ Lift the motor off the pump bracket via the positive guide.
6. ➤ Depending on the motor size remove the threaded pin 6 or the countersunk screw 4.
7. ➤ Pull the outer rotor support 5 and outer rotor 7 off from the motor shaft using mounting levers.
8. ➤ Remove the socket screws 8 between the outer rotor support and the outer rotor.

12.4.2 Removing the inner rotor

Personnel qualification:	<input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Allen key <input type="checkbox"/> Anti-rotation screw




! DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.

Note The containment can is installed in one or more parts.
If a one-piece containment can with a nominal size of 75 mm is installed, the manufacturer recommends replacing the pump flange when replacing this containment can.



1. ➤ Remove the socket screws 9 between the pump 1 and pump bracket 3 and remove the pump bracket.
2. ➤ Remove the socket screws 10 between the containment can 11 and the pump. Remove the containment can. For multi-part containment cans, remove the center flange 16.
3. ➤ To replace the inner rotor 13, turn two screws M into the empty threaded holes of the tensioning element 12 to act as an anti-twist device.

4. ➤ Insert a suitable anti-twist device (e.g. pry bar) between the two screws **M** to fix the clamping element **12**.
5. ➤ Loosen the locking screws of the clamping element **12** with an Allen key and remove the inner rotor **13** from the shaft.
6. ➤ or fix the inner rotor **13** with a strap spanner, loosen the fixing screws of the tensioning elements **12** with the Allen key and remove the inner rotor **13** from the shaft.
7. ➤ For a one-piece containment can with nominal width 75 mm for changing the pump flange: ↪ Servicing, Page 33 "Replacing the ball bearing and screw set".

12.4.3 Installing the inner rotor

Personnel qualification:	<input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Oil without molybdenum sulphide additive (e.g. multifunction spray WD-40)



⚠ DANGER


Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.


- Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.

Requirement:

- ✓ For containment can with nominal width 75 mm: Pump flange fittingly mounted for multipart containment can.



1. ➤ Carefully clean the contact surfaces of the inner rotor **13**, oil the tensioning element **12** lightly.
2. ➤ Manually turn out the screws of the tensioning element by a few turns and insert the tensioning element in the inner rotor.
3. ➤ Carefully clean the sealing surfaces.
4. ➤ Clean and lightly grease the O-ring **15**. Insert the O-ring and slide the distance sleeve **14** onto the pump shaft.
5. ➤ Place the inner rotor with the premounted tensioning element onto the pump shaft and tighten the screws of the tensioning element crosswise by hand.
6. ➤ Check the position of the tensioning element: The tensioning element has to lie flat on the distance sleeve and inner rotor. Otherwise loosen the screws and reposition the tensioning element.
7. ➤ When the position is correct, first tighten the screws of the tensioning element with half the torque crosswise. Subsequently tighten several times crosswise with the full tightening torque ↪ Appendix, Page 63.



8. ➤ Place the containment can **11** and, in case of a multipart containment can, the centering flange **16** on the pump flange and tighten the socket screws **10** with torque.
9. ➤ Place the pump bracket **3** on the pump and tighten the socket screws **9** with torque.

12.4.4 Installing the outer rotor

Personnel qualification:	<input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Hoisting equipment <input type="checkbox"/> Torque wrench <input type="checkbox"/> Positive guide



⚠ DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.




⚠ WARNING


Danger of crushing between motor and pump.

When dismantling/assembling the motor with the pump, the strong magnetic forces can cause sudden collision and therefore injuries to hands or fingers.


- ▶ Use positive guide for disassembly/assembly.
- ▶ Two people are required.
- ▶ Use suitable hoisting equipment (for example chain hoist).
- ▶ Carry out disassembly/assembly in a vertical position if possible.
- ▶ Fix the pump with suitable measures.
- ▶ When the motor is disassembled/assembled, ensure that hands/fingers are not positioned between motor and pump.



1. ➤ Clean the outer rotor **7** carefully with compressed air. Tighten the socket screws **8** between the outer rotor and outer rotor support **5** with torque \rightarrow Appendix, Page 63.
2. ➤ Clean and grease the shaft end of the motor.
3. ➤ Place the outer rotor support with outer rotor on the shaft end of the motor.



4. ➤ Ensure that the shaft end of the motor is flush with the front surface of the outer rotor support.
5. ➤ Depending on the motor size tighten the threaded pin **6** or the countersunk screw **4** with torque.



6. ➤ Fix the pump **1** with suitable means, so that the pump cannot tilt when the motor is mounted.
7. ➤ Attach the hoisting equipment to the motor **2** and position it above the pump.
8. ➤ Insert the positive guide **30** between the motor and the pump bracket **3**.
9. ➤ Place the motor slowly on the pump bracket of the pump. Ensure that the outer rotor **7** does not strike the containment can.
10. ➤ Remove the positive guide.
11. ➤ Screw in the cap screws between the pump bracket and the motor and tighten them with torque.
12. ➤ Make sure that the outer rotor does not rub against the containment can by turning the fan wheel of the motor.
13. ➤ Do not remove the protective cover until just before reconnecting the pump to the pipe system.

12.5 Replacing the ball bearing and screw set

12.5.1 Removing the ball bearing and screw set

Personnel qualification:	<input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Plastic hammer <input type="checkbox"/> Extractor



⚠ DANGER


Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.


- Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.

Requirement:

- ✓ Pump unit disconnected from the electrical power supply, deenergized and secured against being switched back on
- ✓ Magnetic coupling removed



- Remove the socket screws **25** from the pump flange **4** and remove the pump flange with light "re-bound" blows.
- Pull the withdrawable unit (main spindle **2** and the pump flange **4**) out of the pump housing **1**.
- Remove the circlip **8** and the supporting ring **7**.



- Press the main spindle **2** out of the pump flange **4**.
- Remove the Circlip **6** in the pump flange. Pull the ball bearing **10** out of the pump flange **4** using a suitable extractor.
- Remove the idle screws **24** from the pump housing **1**.

12.5.2 Installing the ball bearing and screw set

Personnel qualification:	<input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Mounting sleeve ball bearing

13 Disposal

13.1 Dismantling and disposing of the pump




DANGER

Magnetic field.



Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.

1. ► Clean the fitting surfaces, clean and grease the screw set carefully.



2. ► Insert the idle screws **24** in the pump housing **1**.
3. ► Use the ball bearing mounting sleeve **A** to press the ball bearing **10** into the pump flange **4**, and fasten using the circlip **6**.
4. ► Insert the main spindle **2** into the pump flange **4** and press it into the ball bearing **10** until it reaches the end position.



5. ► Mount the supporting ring **7** and circlip **8**.
6. ► Bond the new flat gasket onto the pump flange **4**.
7. ► Slide the main spindle with premounted pump flange into the pump housing until the main spindle engages into the idle screws. Turn the main spindle while doing so.
8. ► Tighten the socket screws at the pump flange with torque.

Other necessary tasks ↪ Servicing, Page 33

- Install the magnetic coupling

13 Disposal

13.1 Dismantling and disposing of the pump

Personnel qualification:	<input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Face protection <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots
Aids:	<input type="checkbox"/> Solvents or industrial cleaners suitable for the pumped liquid <input type="checkbox"/> Collection tank



DANGER

Magnetic field.

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- ▶ Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.



WARNING

Danger of poisoning and environmental damage through residues.

- ▶ Wear personal protective clothing during all the work. Ensure face protection.
- ▶ Before disposal collect any pumped liquid still present safely and dispose of it in an environmentally compatible manner in accordance with the applicable local regulations.
- ▶ Before disposing neutralize the residues.

Requirement:

- ✓ Disconnect the pump unit from the power supply and secure it against being switched back on
 - ✓ Pump unit cooled down to the ambient temperature and disconnected from the pipe system
 - ✓ Pump emptied completely
 - ✓ Pump placed at a location suitable for dismantling
1. ▶ Dismantle the pump and disassemble it into its individual parts.
 2. ▶ Clean residues of the pumped liquid from the individual parts.
 3. ▶ Separate sealing elements made of elastomers and ceramics (SiC) from the pump and dispose of them in separately.
 4. ▶ Recycle iron parts.

14 Troubleshooting

14.1 Possible faults

Faults can have different causes. The following tables list the symptoms of a fault, the possible causes and measures for troubleshooting.

Identification	Fault
1	No pump suction
2	Delivery rate too low
3	Pump too loud
4	Motor overload
5	Uneven delivery rate
6	Pump has seized
7	Magnetic coupling leaks

14 Troubleshooting

14.2 Troubleshooting

14.2 Troubleshooting

Fault identification							Cause	Remedy
1	–	–	–	–	–	–	Pump suction line closed	<div> <div></div> <div>→ Check the shut-off devices. If required, open.</div> </div>
1	2	3	–	5	–	–	Parts soiled (filter, suction line, suction valve, strainer)	<div> <div></div> <div>→ Clean parts.</div> </div>
1	2	3	–	5	–	–	Suction head too high	<div> <div></div> <div> → Reduce the level difference. -or- Reduce the line length. -or- Increase the line cross-section. -or- Heat up the pumped liquid. -or- Install a filter / strainer with a larger mesh width. Ensure that the permissible mesh width is not exceeded. </div> </div>
1	–	3	–	–	–	–	Level in the intake container too low	<div> <div></div> <div>→ Fill the intake container.</div> </div>
1	–	–	–	–	–	–	Too little pumped liquid in the pump	<div> <div></div> <div>→ Fill the pump with pumped liquid.</div> </div>
1	–	–	–	–	–	–	Incorrect pump direction of rotation	<div> <div></div> <div>→ Swap the two electrical connection phases ↪ Connection, Page 18.</div> </div>
–	–	–	4	–	–	–	Differential pressure too high	<div> <div></div> <div>→ Reduce the differential pressure.</div> </div>
1	–	3	4	5	–	–	Viscosity of the pumped liquid too high	<div> <div></div> <div> → Increase the temperature of the pumped liquid. -or- Decrease the speed. </div> </div>
–	2	–	–	–	–	–	Viscosity of the pumped liquid too low	<div> <div></div> <div> → Reduce the temperature of the pumped liquid. -or- Increase the speed. </div> </div>
–	2	3	–	5	–	–	Airlock/gas in the pumped liquid	<div> <div></div> <div> 1. → Test the pipe system for air admission, replace leaking parts. 2. → Reduce the suction head. -or- Increase the inlet pressure. </div> </div>
–	2	–	4	–	–	–	Speed/frequency/voltage of the motor false	<div> <div></div> <div> 1. → Ensure that the motor frequency and voltage match the operating voltage. 2. → Ensure that the speed of the motor matches the rating plate of the pump. If necessary adjust the speed. </div> </div>
–	2	3	–	5	–	–	Overflow valve opens during normal operation	<div> <div></div> <div>→ Set the opening pressure to 110% of the differential pressure ↪ During operation, Page 25.</div> </div>
–	2	–	–	5	–	–	Overflow valve leaks	<div> <div></div> <div>→ Contact the manufacturer.</div> </div>
–	2	–	–	–	–	–	Advanced wear of the housing/screw set	<div> <div></div> <div>→ Contact the manufacturer.</div> </div>
–	–	3	–	–	–	–	Pump subject to mechanical stress	<div> <div></div> <div>→ Connect the pump correctly to the pipe system ↪ Connection, Page 18.</div> </div>

Fault identification							Cause	Remedy
–	–	3	–	–	–	–	Vibrations/pulsations in the system	<div> <div></div> <div> Bear the pump unit elastically. -or- Make the connections with hoses. </div> </div>
–	–	3	–	–	–	–	Flow speed in the pressure line or suction line too high	<div> <div></div> <div> Set the flow speed in the pressure line so that it does not exceed 3 m/s. -or- Set the flow speed in the suction line so that it does not exceed 1 m/s. -or- Contact the manufacturer. </div> </div>
–	–	3	4	–	–	7	Ball bearing damaged	<div> <div></div> <div> Replace the ball bearing ↗ Servicing, Page 33. </div> </div>
–	–	–	4	–	–	7	Foreign bodies in the pump	<div> <div></div> <div> Contact the manufacturer. </div> </div>
–	–	–	–	–	–	7	Differential pressure is too high and has overloaded the idle screws	<div> <div></div> <div> Contact the manufacturer. </div> </div>
–	–	–	–	–	–	7	Viscosity is too low and has overloaded the idle screws	<div> <div></div> <div> Contact the manufacturer. </div> </div>
1	2	3	4	–	–	7	Pump damaged through dry running	<div> <div></div> <div> Contact the manufacturer. </div> </div>
1	–	–	–	–	–	–	Pump does not vent	<div> <div></div> <div> Vent the pressure line at the highest point. </div> </div>
–	2	3	–	–	–	–	Magnetic coupling interrupted	<div> <div></div> <div> 1. Stop the pump immediately and restart it. 2. Avoid excessive differential pressures. 3. At repeated occurrence check whether pump has got stuck. </div> </div>
1	–	–	–	–	–	7	Containment can defective	<div> <div></div> <div> Replace the containment can ↗ Servicing, Page 33. </div> </div>

Tab. 12: Fault table

15 Accessories

15.1 Heating


15.1.1 Possible types of heating

The pump can optionally be equipped with a heating system. The manufacturer recommends a heating system at high-viscosity pumped liquids that do not flow sufficiently if not heated. This can result in excessive wattage or in problems arising through cavitation or sealing.

Possible types of heating:

- ☐ Electrical heating system
- ☐ Fluid heating system
- ☐ Special heating system

15.1.2 Electrical heating system



- 072** Heating cover
- 481** Heating element
- 1** Connecting cable

Fig. 16: Electrical heating system

The electrical heating system consists of one or two heating elements **481** that are integrated in a heating cover **072** attached additionally to the end cover. The output of the elements corresponds to the radiation losses and convection losses of the pump in the required temperature range so that overheating is not possible.

Size 5 – 118	Size 160 – 2900
1 heating element	2 heating elements
1 heating cover	1 heating cover
4 socket screws	4 socket screws

Tab. 13: Scope of delivery of electrical heating system

Operating data

Parameter	Unit	Value
Voltage	[V]	230
Frequency	[Hz]	50/60
Wire cross-section	[mm ²]	2 x 1

Tab. 14: Operating data electrical heating system

Heating-up period

Required heating-up period for temperature differences of 30 °C or 50 °C:

Size	Wattage [W]	Heating-up period [min] at a temperature difference of	
		30 °C	50 °C
5 – 42	1 x 100	20	35
55 – 118	1 x 220	20	35
160 – 275	2 x 180	25	45
370 – 450	2 x 180	30	60
550 – 660	2 x 250	45	75
851 – 1301	2 x 250	60	90
1500 – 1700	2 x 250	75	120
2200 – 2900	2 x 250	90	150

Tab. 15: Heating-up period for electric heating system

Installing the electrical heating system

Personnel qualification:	<input type="checkbox"/> Electrician
Personal protective equipment:	<input type="checkbox"/> Work clothing
	<input type="checkbox"/> Protective gloves
	<input type="checkbox"/> Safety boots

**! DANGER****Magnetic field.**

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.


ATTENTION

Damage to the electrical heating system through leakage currents or flashovers at the emission point of the connecting cable.

- Protect the area of the connecting head against liquid and pasty liquids (lubricants, oil, plastics, etc.) as well as their vapours.

Requirement:

- ✓ Area of the connecting head protected against liquid and pasty liquids (lubricants, oil, plastics, etc.) as well as their vapours.
- ✓ Supply lines protected against mechanical vibrations in the area of the emission from the heating element. Any vapours arising have to escape freely.
- ✓ Heating element absolutely dry.



- 072** Heating cover
- 481** Heating element
- 1** Connecting cable

Fig. 17: Installation of electrical heating system

- Remove the socket screws and rating plate at the end cover of the pump.
- Mount the heating cover **072** to the end cover using the supplied socket screws.
- Screw the heating element **481** into the heating cover **072**.
- Mount the rating plate on the heating cover **072**.

Connecting the electrical heating system**! DANGER****Risk of death resulting from electric shock.**

- Ensure that the electrical power supply is de-energized and is secured against being switched back on.
- Observe the operating instructions of the electrical components.

- Connect the connecting cable of the heating element.

Commissioning the electrical heating system

**DANGER****Magnetic field.**

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.


- Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.

**DANGER****Risk of injury through discharging pumped liquid.**

The pump housing may burst through heat expansion of the pumped liquid.

- Open all the valves during the heating process.

1. ► Switch on the electric heating system.
2. ► Take the required heating-up periods into account ↪ Accessories, Page 46.

15.1.3 Fluid heating system

- 072** Heating cover
1 Pipe connection

Fig. 18: Fluid heating system

The fluid heating system consists of a heating cover **072** attached additionally to the end cover through which a heating fluid (for example vapour, thermal oil) flows.

Scope of delivery:

Size K 5–2900

1 heating cover

4 socket screws

Tab. 16: Scope of delivery of the fluid heating system

Heating liquid operating data

Parameter	Unit	Value
Max. allowable working pressure	[bar]	16
Max. temperature	[°C]	200

Tab. 17: Heating liquid operating data

Heating-up period

Required heating-up period for the temperature difference of 50 °C at a liquid temperature of 200 °C:

Size	Heating-up period [min] at a temperature difference of 50 °C
5 – 118	20
160 – 275	45
370 – 450	60
550 – 660	90
851 – 1301	120
1500 – 1700	150
2200 – 2900	180

Tab. 18: Heating-up period for fluid heating system


Installing the fluid heating system

Personnel qualification:	<input type="checkbox"/> Fitter
Personal protective equipment:	<input type="checkbox"/> Work clothing <input type="checkbox"/> Protective gloves <input type="checkbox"/> Safety boots

**⚠ DANGER****Magnetic field.**

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.



072 Heating cover
1 Pipe connection

1. ➤ Remove the socket screws and rating plate at the end cover of the pump.
2. ➤ Mount the heating cover **072** to the end cover using the supplied socket screws.
3. ➤ Mount the piping at the pipe connections **1**.
4. ➤ Mount the rating plate on the heating cover.

Commissioning the fluid heating system**⚠ DANGER****Magnetic field.**

Risk of death for persons with cardiac pacemaker, metallic implant or neurostimulator.

- Under no circumstances may persons with cardiac pacemakers, metallic implant or neurostimulator perform work on the pump/pump unit.

**⚠ DANGER****Risk of injury through discharging pumped liquid.**

The pump housing may burst through heat expansion of the pumped liquid.

- Open all the valves during the heating process.

1. ➤ Take the required heating-up periods into account ↗ Accessories, Page 46.
2. ➤ When setting the pressure and temperature of the heating fluid take the permissible operating limits of the pump into account ↗ Technical data, Page 8.

15.1.4 Heating system special design

Please contact the manufacturer for special designs.

16 Spare parts

16.1 Overview

16 Spare parts

16.1 Overview


Model/Size	Type	Variant	Internal
KF/KV 5 – 660	Maintenance kit	Magnetic coupling	OPW 16
KF/KV 851 – 1301	Maintenance kit	Magnetic coupling	OPW 17
KF/KV 1500 – 1700	Maintenance kit	Magnetic coupling	OPW 18
KF/KV 2200 – 2900	Maintenance kit	Magnetic coupling	OPW 19
KFN/KFT/KVT 2200 – 2900	Maintenance kit	Magnetic coupling	OPW 20
KF/KV/KV 5 – 660 and KFT/KVT/KFN/KFA	Repair kit	Overflow valve	OPR 01
KF/KH/KV 851 – 1301	Repair kit	Overflow valve	OPR 02
KF/KH/KV 1500 – 1700	Repair kit	Overflow valve	OPR 03
KF/KH/KV 2200 – 2900	Repair kit	Overflow valve	OPR 04
K	Repair kit	Screw set	OPR 05
KF/KV/KFT/KVT/KFA	Repair kit	Magnetic coupling	OPR 06
KF	Spare parts	Completion	UKF
KV	Spare parts	Completion	UKF

Tab. 19: Overview of spare parts

16.2 Maintenance kits

16.2.1 Maintenance kit magnetic coupling KF/KV 5 – 660


Note The maintenance kit contains only the numbered parts and is only supplied complete.



Qty.	Item No.	Part	Qty.	Item No.	Part
1	055*	Supporting ring	1	729.5	Flat gasket
1	056	Supporting ring	1	729.6	Flat gasket, suction flange
1	165.1	Screw plug	1	729.7	Flat gasket, pressure flange
4	165.2	Screw plug	1/2	739****	O-ring
1	165.3	Screw plug	1	817	Ball bearing
1	471.2	Circlip	4	914.1	Socket screw
1	471.2*	Circlip	4	914.2	Socket screw
1	471.3	Circlip	4	914.9**	Socket screw
1	729.4	Flat gasket	1		Mounting sleeve ball bearing
	*	Only for size 5 – 20			
	**	Only for Type KV: replaces 914.2			
	***	Size 5 – 275: Containment can is installed one or more parts			
	****	Size 5 – 275:Use matching O-ring			

Tab. 20: Maintenance kit magnetic coupling KF/KV 5 – 660

Note The maintenance kit contains only the numbered parts and is only supplied complete.




Qty.	Item No.	Part	Qty.	Item No.	Part
1	055	Supporting ring	1	729.6	Flat gasket, suction flange
1	056	Supporting ring	1	729.7	Flat gasket, pressure flange
1	165.1	Screw plug	1	739	O-ring
4	165.2	Screw plug	1	817	Ball bearing
1	165.3	Screw plug	4	914.1	Socket screw
1	471.2	Circlip	4	914.2	Socket screw
1	471.3	Circlip	1	914.8	Socket screw
1	729.4	Flat gasket	4	914.9*	Socket screw
1	729.5	Flat gasket	1		Mounting sleeve ball bearing
	*	Only for Type KV: replaces 914.2			

Tab. 21: Maintenance kit magnetic coupling KF/KV 851 – 1301

16.2.3 Maintenance kit magnetic coupling KF/KV 1500 – 1700

Note The maintenance kit contains only the numbered parts and is only supplied complete.



Qty.	Item No.	Part	Qty.	Item No.	Part
1	055	Supporting ring	1	729.6	Flat gasket, suction flange
1	056	Supporting ring	1	729.7	Flat gasket, pressure flange
1	165.1	Screw plug	1	739	O-ring
4	165.2	Screw plug	1	817	Ball bearing
1	165.3	Screw plug	8	914.1	Socket screw
1	471.2	Circlip	7	914.2	Socket screw
1	471.3	Circlip	3	914.8	Socket screw
1	729.4	Flat gasket	4	914.9*	Socket screw
1	729.5	Flat gasket	1		Mounting sleeve ball bearing
*		Only for Type KV: replaces 914.2			


Tab. 22: Maintenance kit magnetic coupling KF/KV 1500 – 1700

16 Spare parts

16.2 Maintenance kits

16.2.4 Maintenance kit magnetic coupling KF/KV 2200 – 2900

Note The maintenance kit contains only the numbered parts and is only supplied complete.




Qty.	Item No.	Part	Qty.	Item No.	Part
1	055	Supporting ring	1	729.7	Flat gasket, pressure flange
1	057	Threaded ring	1	739	O-ring
1	165.1	Screw plug	1	817	Ball bearing
4	165.2	Screw plug	8	914.1	Socket screw
1	165.3	Screw plug	7	914.2	Socket screw
1	471.3	Circlip	3	914.8	Socket screw
1	729.4	Flat gasket	4	914.9*	Socket screw
1	729.5	Flat gasket	1		Mounting sleeve ball bearing
1	729.6	Flat gasket, suction flange			
	*	Only for Type KV: replaces 914.2			

Tab. 23: Maintenance kit magnetic coupling KF/KV 2200 – 2900

16.2.5 Maintenance kit magnetic coupling KFN/KFT/KVT

Note The maintenance kit contains only the numbered parts and is only supplied complete.




Qty.	Item No.	Part	Qty.	Item No.	Part
1	055*	Supporting ring	1	729.5	Flat gasket
1	056	Supporting ring	1	729.6	Flat gasket, suction flange
1	165.1	Screw plug	1	729.7	Flat gasket, pressure flange
4	165.2	Screw plug	1/2	739****	O-ring
1	165.3	Screw plug	1	817	Ball bearing
1	471.2	Circlip	4	914.1	Socket screw
1	471.2*	Circlip	4	914.2	Socket screw
1	471.3	Circlip	4	914.9**	Socket screw
1	729.4	Flat gasket	1		Mounting sleeve ball bearing
*		Only for Size 5 – 20			
**		Only for Type KV: replaces 914.2			
***		Size 5 – 275: Containment can is installed one or more parts			
****		Size 5 – 275: Use matching O-ring			

Tab. 24: Maintenance kit magnetic coupling KFN/KFT/KVT


16.3 Repair kits

16.3.1 Repair kit overflow valve KF/KH/KV 5 – 660 and KFT/KVT/KFN/KFA

Note The repair kit contains only the numbered parts and is only supplied complete.




Qty.	Item No.	Part	Qty.	Item No.	Part
1	164	Adjusting screw	1	501	Pressure spring
1	165.1	Screw plug	1	729.4	Flat gasket
1	305	Valve body	4	914.2	Socket screw

	Type KFA: Pump housing with overhead flanges in special design PN16
---	---

Tab. 25: Repair kit overflow valve KF/KH/KV 5 – 660 and KFT/KVT/KFN/KFA

16.3.2 Repair kit overflow valve KF/KH/KV 851 – 1301

Note The repair kit contains only the numbered parts and is only supplied complete.




Qty.	Item No.	Part	Qty.	Item No.	Part
1	064	Supporting ring	1	629	Valve housing
1	164	Adjusting screw	1	729.4	Flat gasket
1	165.1	Screw plug	7	914.2	Socket screw
1	305	Valve body	1	914.5	Socket screw
1	306	Groove nut	4	914.6*	Socket screw
1	501	Pressure spring			
	*	Only for Type KV: replaces 4 pieces 914.2			

Tab. 26: Repair kit overflow valve KF/KH/KV 851 – 1301

16.3.3 Repair kit overflow valve KF/KH/KV 1500 – 1700

Note The repair kit contains only the numbered parts and is only supplied complete.




Qty.	Item No.	Part	Qty.	Item No.	Part
2	064	Supporting ring	1	629	Valve housing
1	164	Adjusting screw	1	729.4	Flat gasket
1	165.1	Screw plug	7	914.2	Socket screw
1	305	Valve body	3	914.5	Socket screw
1	306	Groove nut	4	914.6*	Socket screw
1	501	Pressure spring			
	*	Only for Type KV: replaces 4 pieces 914.2			

Tab. 27: Repair kit overflow valve KF/KH/KV 1500 – 1700

16.3.4 Repair kit overflow valve KF/KH/KV 2200 – 2900

Note The repair kit contains only the numbered parts and is only supplied complete.




Qty.	Item No.	Part	Qty.	Item No.	Part
1	039	Sleeve	1	501	Pressure spring
1	064	Supporting ring	1	629	Valve housing
1	164	Adjusting screw	1	729.4	Flat gasket
1	165.1	Screw plug	7	914.2	Socket screw
1	305	Valve body	3	914.5	Socket screw
1	306	Groove nut	4	914.6*	Socket screw
* Only for Type KV: replaces 4 pieces 914.2					

Tab. 28: Repair kit overflow valve KF/KH/KV 2200 – 2900

16.3.5 Repair kit, screw set

Note The repair kit is only supplied in combination with a maintenance kit.



Qty.	Item No.	Part	Qty.	Item No.	Part
1	042	Balancing cylinder	1	661	Screw set
1	471.1	Circlip			


Tab. 29: Repair kit, screw set

16 Spare parts

16.3 Repair kits

16.3.6 Repair kit magnetic coupling

Note The repair kit contains only the numbered parts and is only supplied complete.




Qty.	Item No.	Part	Qty.	Item No.	Part
1	038	Containment can	1	585	Tensioning element
1	040	Distance sleeve	1	729.5	Flat gasket pump flange
1	052	Outer coupling hub	1	739	O-ring
4	063**	Supporting ring	1	884**	Threaded pin
1	074***	Pump flange	1	914.4	Socket screw
1	110***	Centering flange	1	914.5	Socket screw
1	515	Outer rotor	1	917**	Countersunk screw
1	518	Inner rotor	4	917.1**	Countersunk screw
	**	Depending on motor size			
	***	Magnetic coupling nominal size 75 mm			
	****	Magnetic coupling nominal size ≥110 mm			

Tab. 30: Repair kit magnetic coupling KF/KV/KFT/KVT/KFA

16.4 Completions


16.4.1 Completion Type KF



Qty.	Item No.	Part	Qty.	Item No.	Part
1	180	Pump bracket	4	914.3	Socket screw
1	526	Pump bracket foot	4	914.6	Socket screw
3	894	Hexagon nut	3	914.7	Socket screw

Tab. 31: Completion Type KF

16.4.2 Completion Type KV



Qty.	Item No.	Part	Qty.	Item No.	Part
1	180	Pump bracket	4	914.6	Socket screw
1	663	Pedestal	4	914.9	Socket screw
8	914.3	Socket screw			

Tab. 32: Completion Type KV

17.1 Tightening torques for screws with metric screw threads with and without wedge lock washers

17 Appendix

17.1 Tightening torques for screws with metric screw threads with and without wedge lock washers

Note In the case of galvanised screw plugs and screw plugs made of stainless steel the inner thread and outer thread have to be greased thorough before mounting in order to prevent threads from seizing.

Note The manufacturer recommends tightening screws with wedge lock washers according to the table three times after another with the same tightening torque

Tightening torque [Nm]							
Screws with head contact surface					Countersunk screws		
Thread					Stainless steel screws A2 and A4		8.8
	5.6	8.8	10.9	8.8+ Alu*	Property class 70	Property class 80	
M 3	0.6	1.5	–	1.2	1.1	1.3	1.0
M 4	1.4	3.0	4.1	2.3	2.0	2.3	2.0
M 5	2.7	6.0	8.0	4.8	3.9	4.7	5.0
M 6	4.7	10.3	14.0	7.6	6.9	8.0	9.0
M 8	11.3	25.0	34.0	18.4	17.0	22.0	14.0
M 10	23.0	47.0	68.0	36.8	33.0	43.0	36.0
M 12	39.0	84.0	117	64.0	56.0	75.0	60.0
M 14	62.0	133	186	101	89.0	–	90.0
M 16	96.0	204	285	155	136	180	100
M 18	133	284	390	224	191	–	–
M 20	187	399	558	313	267	370	135
M 24	322	687	960	540	460	605	360

Tab. 33: Tightening torques metric screw thread

*When screwing into aluminium, the tightening torque reduces by 20 % when the screw-in depth is less than double the thread diameter.

17.2 Tightening torques for screw plugs with thread measured in inches and elastomer seal

Note In the case of galvanised screw plugs and screw plugs made of stainless steel the inner thread and outer thread have to be greased thorough before mounting in order to prevent threads from seizing.

Tightening torque [Nm]	
Thread	Galvanized + stainless steel
G 1/8"	13.0
G 1/4"	30.0
G 3/8"	60.0
G 1/2"	80.0
G 3/4"	120
G 1"	200
G 1 1/4"	400
G 1 1/2"	450

Tab. 34: Tightening torques with thread measured in inches

17.3 Tightening torques for screws of tensioning elements

Tightening torque [Nm]	
Thread	12.9
M 3	2.1
M 4	5.1
M 6	17.4
M 8	42.2
M 10	83.0
M 12	144

Tab. 35: Tightening torques tensioning elements

17.4 Contents of the Declaration of Conformity

The products described in these instructions are machinery in the sense of the Directive 2006/42/EC. The original of the EC Declaration of Conformity is enclosed with the machinery at delivery.

The machinery fulfils all the relevant provisions of the following directives:

Number	Name	Remark
2006/42/EC	Machinery Directive	–
2014/68/EU	Pressure Equipment Directive	–
2014/30/EU	Directive on Electromagnetic Compatibility	Only for machinery with electrical components
2014/35/EU	Low Voltage Directive	Only for machinery with electrical components
2014/34/EU	Directive on Use in Potentially Explosive Areas (ATEX)	Only for machinery in ATEX version

Tab. 36: Directives observed



KRAL

